

Kingtronics® Potentiometer Cross-Reference Guide

| ACP Vimex | Kingtronics | THROUGH-HOLE/MULTITURN | SURFACE MOUNT/MULTITURN (Contd.) | THROUGH-HOLE/SINGLE-TURN (Contd.) | THROUGH-HOLE/SINGLE-TURN (Contd.) | SURFACE MOUNT/SINGLE-TURN (Contd.) | THROUGH-HOLE/SINGLE-TURN (Contd.) | WIREWOUND (Contd.) | THROUGH-HOLE/SINGLE-TURN (Contd.) | Murata | Kingtronics |
|--------------------------|-------------|---------------------------|----------------------------------|---------------------------------------|--|------------------------------------|-----------------------------------|--------------------|-----------------------------------|------------------------------------|-------------|
| THROUGH-HOLE/SINGLE-TURN | | CE7ST-E No Cross | 45GE No Cross | 25RV No Cross | TR07P 3386P | ST-32ETA No Cross | CT-6ES 3362S | 113T No Cross | VZ083H 3309W | SURFACE MOUNT | |
| CA6V5 3318F | | CE12ST No Cross | 45G No Cross | 25S 3362S | TR08A 3362S | ST-32ETB No Cross | CT-6ETH 3362M | 1113TR No Cross | VZ083L 3309P | Murata | Murata |
| CA6VS5 3318F | | CE9STWW No Cross | 45JE No Cross | 25U 3362U | TR08H 3362X | ST-32ETG No Cross | CT-6ETP No Cross | 1208P No Cross | VZ087H 3309W | New P/N Old P/N Kingtronics | |
| CA6V2.5 No Cross | | CE6MT-W 3266W | 45J No Cross | 25V 3362M | TR08X 3362W | ST-32ETH No Cross | CT-6ETV 3362U | 1211L No Cross | VZ087L 3309P | PV01P PV01P 3269P | |
| CA6H2.5 No Cross | | CE6MT-Y 3266Y | 45WE No Cross | 25W 3362H | TR08W 3362M | ST-32G No Cross | CT-6EV 3362U | 1211LB No Cross | | PV01W PV01W 3269W | |
| CA6VSMD No Cross | | CE6MT-P 3266P | 45W No Cross | 25X 3362X | Citec/Meggitt Kingtronics | | CT-6EW 3362H | 1211P No Cross | | PV01X PV01X 3269X | |
| CA6HSMD No Cross | | CE6MT-X 3266X | 84P 3269P | 62B No Cross | THROUGH-HOLE/SINGLE-TURN | ST-32TA No Cross | CT-6EX 3362W | 1211PB No Cross | | | |
| | | CE6MT-Z 3266Z | 84W 3269W | 62M 3329P | | 224-424 No Cross | ST-32TB No Cross | CT-6F No Cross | 1309P No Cross | | |
| CA9V10 No Cross | | CE10MT-W 3296W | 84X 3269X | 62PF No Cross | | ST-32TG No Cross | CT-6G 3362M | 1309W No Cross | | | |
| CA9V7.5 No Cross | | CE10MT-Y 3296Y | THROUGH-HOLE / MULTITURN | | 62P No Cross | ST-32TH No Cross | CT-6MP 3362P | 1309X No Cross | | | |
| CA9VR10 No Cross | | CE10MT-P 3296P | 56BW No Cross | 72PE 3386P-EY5 | THROUGH-HOLE/SINGLE-TURN | ST-3A No Cross | CT-6MS 3362S | | | | |
| CA9MAV10 No Cross | | CE10MT-X 3296X | 64PF No Cross | 72PLE 3386T-EY5 | | 405 No Cross | ST-3TA No Cross | CT-6N 3362X | CTS Kingtronics | | |
| CA9MTV10 No Cross | | CE10MT-Z 3296Z | 64P 3266P | 72PL 3386T | 406 3306 | SURFACE MOUNT/SINGLE-TURN | | 303U No Cross | | | |
| CA9H2.5 No Cross | | CE13MT No Cross | 64WF No Cross | 72PM 3386F-EY5 | 409 3309 | 306U 3362P | | | | | |
| CA9H5 No Cross | | CE12MT-P No Cross | 64W 3266W | 72PME 3386F | 410 3309 | 306H 3362U | | | | | |
| CA9H3.8 No Cross | | CE19MT-P 3006P | 64XF No Cross | 72PM 3386F | 414 No Cross | 306J 3362X | | | | | |
| CA9HS3.8 No Cross | | CE19MT-P-WT 3006P(Z) | 64YF No Cross | 72P 3386P | 433 3006 | 306K 3362M | | | | | |
| CA14 Series No Cross | | CE19MTB-P 3006P(Z) | 64ZF No Cross | 72PT 3386P(T) | 470 3329 | 306X 3362S | | | | | |
| CE10ST-F 3386F | | CE32MT-L No Cross | 64Z 3266Z | 72PXE 3386M-EY5 | 3130 C3305 | 307U 3306F | | | | | |
| CE10ST-P 3386P | | CE32MT-P No Cross | 66P 3296P | 72RPE 3386M | 3140 No Cross | 307X 3306K | | | | | |
| CE10ST-R 3386R | | CE32MT-T No Cross | 66W 3296W | 72RP 3386P | 3150 No Cross | 201X-RS No Cross | | | | | |
| CE10ST-U 3386U | | CE32MT-Y No Cross | 66X 3296X | 72RPXE 3386R-EY5 | 3165 No Cross | 201U-RS No Cross | | | | | |
| CE10ST-W 3386W | | CE13MTWW No Cross | 67P 3296P | 72RWE 3386W-EY5 | 3203 No Cross | 201H-RS No Cross | | | | | |
| CE10ST-B 3386B | | CE19MT-P No Cross | 67W 3296W | 72RWF 3386W | 3204 No Cross | U262 No Cross | | | | | |
| CE10ST-C 3386C | | CE19MTB-P No Cross | 67X 3296X | 72RW 3386W | 3270 3269 | X262 No Cross | | | | | |
| CE10ST-H 3386H | | CE32MT-L No Cross | 67Y 3296Y | 72RXE 3386H-EY5 | 3315 No Cross | 110U No Cross | | | | | |
| CE10ST-S 3386S | | CE32MT-P No Cross | 67Z 3296Z | 72RXLE 3386W-EY5 | 4255 3362 | 110M No Cross | | | | | |
| CE10ST-X 3386X | | CE32MT-T No Cross | CA3V-SMD No Cross | 72RXL 3386W | 4270 3266 | 115 No Cross | | | | | |
| CE10ST-W 3386W | | CE32MT-Y No Cross | CA6VSMD 3361P | 72RXWE 3386S-EY5 | 4290 3296 | P115 No Cross | | | | | |
| CE10ST-B-WT 3386B-EY5 | | CE13MTWW No Cross | CA6HSMD 3361S | 72XE 3386X-EY5 | 4295 3386 | 116 No Cross | | | | | |
| CE10ST-C-WT 3386C-EY5 | | SURFACE MOUNT/SINGLE-TURN | | 72XLE 3386C-EY5 | CP10 No Cross | 117 No Cross | | | | | |
| CE10ST-H-WT 3386H-EY5 | | CA3V-SMD No Cross | | 72XL 3386X | ClaroStat Honeywell Kingtronics | | | | | | |
| CE10ST-S-WT 3386S-EY5 | | CA6VSMD 3361P | | 72XT 3386X(T) | THROUGH-HOLE/MULTITURN | FT-63EH 3362M | | | | | |
| CE10ST-X-WT 3386X-EY5 | | CA6HSMD 3361S | | 72XWE 3386B-EY5 | 343P 3006P | FT-63EN 3362X | | | | | |
| CE10ST-W-WT 3386W-EY5 | | | | 72XW 3386B | 364P 3296P | FT-63EV 3362U | | | | | |
| CE9V10 3309P-1 | | SURFACE MOUNT/MULTITURN | | 82M 3329P | 364X 3296X | FT-63EX 3362W | | | | | |
| CE9V7.5 No Cross | | CE4MT-SMD-W No Cross | | 82PA 3329W | 364W 3296W | FT-63TH 3362M | | | | | |
| CE9VR10 3309P-1 | | CE6MT-SMD-W 3269W | | 82PF No Cross | 364Y 3296Y | FT-63TP 3362P | | | | | |
| CE9MAV10 No Cross | | CE6MT-SMD-X 3269X | | 82W No Cross | 370L No Cross | FT-63TS No Cross | | | | | |
| CE9MTV10 3309P | | CE6MT-SMD-P 3269P | | 91A No Cross | 370Y No Cross | FT-63TV 3362U | | | | | |
| CE9H2.5 3309W | | | | 91B No Cross | Type N No Cross | | | | | | |
| CE9H5 No Cross | | | | 91C No Cross | Type R No Cross | | | | | | |
| CE9H3.8 No Cross | | | | 91E No Cross | THROUGH-HOLE/SINGLE-TURN | | | | | | |
| CE9HS3.8 No Cross | | | | 91T No Cross | 363M 3386F | | | | | | |
| CE14 Series No Cross | | | | 91W No Cross | 363P 3386U | | | | | | |
| TG625HSC 3306P | | | | 91X No Cross | 363X 3386X | | | | | | |
| RVM-06-HP03-1 3306F | | | | 93P No Cross | 383-5 No Cross | | | | | | |
| RVM-06-VP01-1 3306K | | | | C&K/ITT Cannon Kingtronics | | | | | | | |
| RVM-08-HP05-1 3309P | | | | TR62P 3006P | 383RA1 No Cross | | | | | | |
| RVM-08-VP01-1 3309W | | | | TR62P C No Cross | 367T 3362H | | | | | | |
| CE6ST-P 3329P | | | | TR62Y 3006Y | Type F No Cross | | | | | | |
| CE6ST-H 3329H | | | | TR52P No Cross | Type SV/H No Cross | | | | | | |
| CE6ST-H-1 3329H | | | | TR53S No Cross | Type Y No Cross | | | | | | |
| CE6STLP-H No Cross | | | | WIREWOUND | | | | | | | |
| CE6STLP-HA No Cross | | | | TR03G No Cross | U580 No Cross | | | | | | |
| CE6STM-V No Cross | | | | TR03J No Cross | Copal-Philips(BC) Kingtronics | | | | | | |
| CE6ST-S 3329S | | | | TR04G No Cross | SURFACE MOUNT/SINGLE-TURN | | | | | | |
| CE6ST-X 3329X | | | | TR04J No Cross | ST-2A No Cross | | | | | | |
| CE6STLP-S No Cross | | | | TR04H No Cross | ST-2TA No Cross | | | | | | |
| CE6STLP-SA No Cross | | | | TR04SA No Cross | ST-32A No Cross | | | | | | |
| CE6STM-H No Cross | | | | THROUGH-HOLE/SINGLE-TURN | | ST-32B No Cross | | | | | |
| CE7ST-P 3362P | | | | TR06C 3362U | ST-32EA No Cross | CT-6EF No Cross | | | | | |
| CE7ST-R 3362R | | | | TR06H 3362H | ST-32EG No Cross | CT-6EH 3362M | | | | | |
| CE7ST-U 3362U | | | | TR06P 3362P | ST-32EH No Cross | CT-6EMP 3362P | | | | | |
| CE7ST-M 3362M | | | | TR07F 3386F | THROUGH-HOLE/SINGLE-TURN | CT-6ETG 3362U | | | | | |
| CE7ST-S 3362S | | | | THROUGH-HOLE / MULTITURN | | CT-6ETH 3362M | | | | | |
| CE7ST-X 3362X | | | | 24 Series No Cross | 24 Series No Cross | CT-6ETV 3362U | | | | | |
| CE7ST-W 3362W | | | | 25P 3362P | 25P 3362P | CT-6EV 3362U | | | | | |
| CE7ST-C No Cross | | | | 25RS 3362Z | 25RS 3362Z | CT-6EW 3362H | | | | | |
| | | | | 25RX 3362W | 25RX 3362W | CT-6EX 3362W | | | | | |
| | | | | | | CT-6F No Cross | | | | | |
| | | | | | | CT-6G 3362M | | | | | |
| | | | | | | CT-6H No Cross | | | | | |
| | | | | | | CT-6I No Cross | | | | | |
| | | | | | | CT-6J No Cross | | | | | |
| | | | | | | CT-6K No Cross | | | | | |
| | | | | | | CT-6L No Cross | | | | | |
| | | | | | | CT-6M No Cross | | | | | |
| | | | | | | CT-6N No Cross | | | | | |
| | | | | | | CT-6O No Cross | | | | | |
| | | | | | | CT-6P No Cross | | | | | |
| | | | | | | CT-6Q No Cross | | | | | |
| | | | | | | CT-6R No Cross | | | | | |
| | | | | | | CT-6S No Cross | | | | | |
| | | | | | | CT-6T No Cross | | | | | |
| | | | | | | CT-6U No Cross | | | | | |
| | | | | | | CT-6V No Cross | | | | | |
| | | | | | | CT-6W No Cross | | | | | |
| | | | | | | CT-6X No Cross | | | | | |
| | | | | | | CT-6Y No Cross | | | | | |
| | | | | | | CT-6Z No Cross | | | | | |
| | | | | | | CT-6AA No Cross | | | | | |
| | | | | | | CT-6AB No Cross | | | | | |
| | | | | | | CT-6AC No Cross | | | | | |
| | | | | | | CT-6AD No Cross | | | | | |
| | | | | | | CT-6AE No Cross | | | | | |
| | | | | | | CT-6AF No Cross | | | | | |
| | | | | | | CT-6AG No Cross | | | | | |
| | | | | | | CT-6AH No Cross | | | | | |
| | | | | | | CT-6AI No Cross | | | | | |
| | | | | | | CT-6AJ No Cross | | | | | |
| | | | | | | CT-6AK No Cross | | | | | |
| | | | | | | CT-6AL No Cross | | | | | |
| | | | | | | CT-6AM No Cross | | | | | |
| | | | | | | CT-6AN No Cross | | | | | |
| | | | | | | CT-6AO No Cross | | | | | |
| | | | | | | CT-6AP No Cross | | | | | |
| | | | | | | CT-6AQ No Cross | | | | | |
| | | | | | | CT-6AR No Cross | | | | | |
| | | | | | | CT-6AS No Cross | | | | | |
| | | | | | | CT-6AT No Cross | | | | | |
| | | | | | | CT-6AU No Cross | | | | | |
| | | | | | | CT-6AV No Cross | | | | | |
| | | | | | | CT-6AW No Cross | | | | | |
| | | | | | | CT-6AX No Cross | | | | | |
| | | | | | | CT-6AY No Cross | | | | | |
| | | | | | | CT-6AZ No Cross | | | | | |
| | | | | | | CT-6BA No Cross | | | | | |
| | | | | | | CT-6BB No Cross | | | | | |
| | | | | | | CT-6BC No Cross | | | | | |
| | | | | | | CT-6BD No Cross | | | | | |
| | | | | | | CT-6BE No Cross | | | | | |
| | | | | | | CT-6BF No Cross | | | | | |
| | | | | | | CT-6BG No Cross | | | | | |
| | | | | | | CT | | | | | |

Kingtronics® Potentiometer Cross-Reference Guide

| Noble | Kingtronics |
|---------------------------|-------------|
| SURFACE MOUNT/SINGLE-TURN | |
| TMC3 | C3305 |
| THROUGH-HOLE/SINGLE-TURN | |
| VM5CK-PV | No Cross |
| VM6CK-PV | 3306F |
| VM6CK-PV (1S) | 3306F |
| VM6CK-PH | 3306W |
| VM6CK-PH (1S) | 3306W |
| TM4K5-2 | No Cross |
| TM6K3-2 | No Cross |
| TM64K2 (PV) | 3306P |
| TM64K2 (PH) | 3306K |
| TM62K (PV) | 3306P |
| TM62K (PH) | 3306W |
| TM8KV2-1S | 3309P |
| TM8KH1-1S | No Cross |
| TM10K (PV) | 3306F |
| TM10K (PH) | No Cross |
| V6EK-PV | 3318F |
| V6EK-PH | 3318K |
| V8K4-11 | No Cross |
| V8K1-1 | No Cross |
| V8K1-11 (1S) | No Cross |
| Panasonic | Kingtronics |
| SURFACE MOUNT/SINGLE-TURN | |
| EVM1DSW/X | No Cross |
| EVM1ESW/X | No Cross |
| EVM1SSW/X | C3305 |
| EVM1U | No Cross |
| EVM1XSW/X | No Cross |
| EVM2WS | No Cross |
| EVM2X | No Cross |
| EVM3SSW/X | C3305 |
| EVM3VS | C3305 |
| EVM3WS | No Cross |
| EVM3Y | C3305 |
| EVM7J | No Cross |
| EVM7L | No Cross |
| EVN5CSW/X | No Cross |
| EVN5ESW/X | No Cross |
| THROUGH-HOLE/SINGLE-TURN | |
| EVM31G | 3306W |
| EVM4LG | 3306F |
| EVM5AG | No Cross |
| EVMA | No Cross |
| EVMEA | No Cross |
| EVMEEG | No Cross |
| EVMEES | No Cross |
| EVMEGG | 3306K |
| EVMEGS | No Cross |
| EVMEYS | No Cross |
| EVML1G | No Cross |
| EVML4G | No Cross |
| EVMMAG | 3362R |
| EVMMBG | 3362S |
| EVMMSG | 3362H |
| EVNCYA | 3318F (A) |
| EVND2AA03B12 | 3318K |
| EVND8AA03B12 | 3318F |
| EVND8M | No Cross |
| EVNDCA | No Cross |
| EVNDJA | 3318F (A) |
| EVNDXA | 3318F (A) |
| EVNGBA | No Cross |

| Piher | Kingtronics |
|---------------------------|-------------|
| SURFACE MOUNT/SINGLE-TURN | |
| SC-3 | C3305 |
| SC-4 | No Cross |
| THROUGH-HOLE/SINGLE-TURN | |
| N-6S 25 TOC | No Cross |
| N-6L 25 TOC | No Cross |
| N-6L 30 TOC | No Cross |
| N-6L 50 TOC | No Cross |
| N-6L 50 TOS | No Cross |
| N-6S 25 T1/T3 | No Cross |
| N-6L 25 T1/T3 | No Cross |
| N-6L 30 T1/T3 | No Cross |
| NC-6S 25 T4N | No Cross |
| NC-6L 30 T4N | No Cross |
| NC-6S 25 TOC | 3306W |
| NC-6L 50 TOC | 3306F |
| PT-6KH | 3318K |
| PT-6MH | No Cross |
| PT-6WH | No Cross |
| PT-6XH | No Cross |
| PT-6KV | 3318F |
| PT-6MV | No Cross |
| PT-6WV | No Cross |
| PT-10GH01 | 105 Series |
| PT-10LH01 | 105 Series |
| PT-10MH01 | 105 Series |
| PT-10KH01 | 105 Series |
| PT-10XH01 | 105 Series |
| PT-10WH01 | 105 Series |
| PT-10YH01 | 105 Series |
| PT-10ZH01 | 105 Series |
| PT-10GH05 | 105 Series |
| PT-10LH05 | 105 Series |
| PT-10MH05 | 105 Series |
| PT-10YH05 | 105 Series |
| PT-10ZH05 | 105 Series |
| PT-10GH02 | 105 Series |
| PT-10LH02 | 105 Series |
| PT-10MH02 | 105 Series |
| PT-10KH02 | 105 Series |
| PT-10XH02 | 105 Series |
| PT-10WH02 | 105 Series |
| PT-10YH02 | 105 Series |
| PT-10ZH02 | 105 Series |
| PT-10GH10 | 105 Series |
| PT-10LH10 | 105 Series |
| PT-10MH10 | 105 Series |
| PT-10KH10 | 105 Series |
| PT-10XH10 | 105 Series |
| PT-10WH10 | 105 Series |
| PT-10YH10 | 105 Series |
| PT-10ZH10 | 105 Series |
| PT-10GV05 | 105 Series |
| PT-10LV05 | 105 Series |
| PT-10MV05 | 105 Series |
| PT-10KV05 | 105 Series |
| PT-10XV05 | 105 Series |
| PT-10WV05 | 105 Series |
| PT-10YV05 | 105 Series |
| PT-10GV10 | 105 Series |
| PT-10LV10 | 105 Series |
| PT-10MV10 | 105 Series |
| PT-10KV10 | 105 Series |
| PT-10XV10 | 105 Series |
| PT-10WV10 | 105 Series |
| PT-10YV10 | 105 Series |
| PT-10GV11 | 105 Series |
| PT-10LV11 | 105 Series |
| PT-10MV11 | 105 Series |

| THROUGH-HOLE/SINGLE-TURN (Contd.) | |
|-----------------------------------|----------|
| PT-10KV11 | No Cross |
| PT-10XV11 | No Cross |
| PT-10WV11 | No Cross |
| PT-10YV11 | No Cross |
| PT-10GV13 | No Cross |
| PT-10LV13 | No Cross |
| PT-10MV13 | No Cross |
| PT-10KV13 | No Cross |
| PT-10XV13 | No Cross |
| PT-10WV13 | No Cross |
| PT-10YV13 | No Cross |
| PTC-10GH01 | 3309W-3 |
| PTC-10LH01 | 3309W-2 |
| PTC-10MH01 | 3309W-3 |
| PTC-10KH01 | 3309W-2 |
| PTC-10XH01 | No Cross |
| PTC-10WH01 | No Cross |
| PTC-10YH01 | No Cross |
| PTC-10ZH01 | No Cross |
| PTC-10GH05 | No Cross |
| PTC-10LH05 | No Cross |
| PTC-10MH05 | No Cross |
| PTC-10KH05 | No Cross |
| PTC-10XH05 | No Cross |
| PTC-10WH05 | No Cross |
| PTC-10YH05 | No Cross |
| PTC-10ZH05 | No Cross |
| PT w/ detents | No Cross |
| PT-15 | No Cross |
| PTC-10WH05 | No Cross |
| PTC-10YH05 | No Cross |
| PTC-10ZH05 | No Cross |
| PTC-10GH02 | 3309W-3 |
| PTC-10LH02 | 3309W-2 |
| PTC-10MH02 | 3309W-3 |
| PTC-10KH02 | 3309W-2 |
| PTC-10XH02 | No Cross |
| PTC-10WH02 | No Cross |
| PTC-10YH02 | No Cross |
| PTC-10ZH02 | No Cross |
| PTC-10GH10 | No Cross |
| PTC-10LH10 | No Cross |
| PTC-10MH10 | No Cross |
| PTC-10KH10 | No Cross |
| PTC-10XH10 | No Cross |
| PTC-10WH10 | No Cross |
| PTC-10YH10 | No Cross |
| PTC-10ZH10 | No Cross |
| PTC-10GV05 | No Cross |
| PTC-10LV05 | No Cross |
| PTC-10MV05 | No Cross |
| PTC-10KV05 | No Cross |
| PTC-10XV05 | No Cross |
| PTC-10WV05 | No Cross |
| PTC-10YV05 | No Cross |
| PTC-10GV10 | 3309P-3 |
| PTC-10LV10 | 3309P-2 |
| PTC-10MV10 | 3309P-3 |
| PTC-10KV10 | 3309P-2 |
| PTC-10XV10 | No Cross |
| PTC-10WV10 | No Cross |
| PTC-10YV10 | No Cross |
| PTC-10GV11 | 3309P-3 |
| PTC-10LV11 | 3309P-2 |
| PTC-10MV11 | 3309P-3 |
| PTC-10KV11 | 3309P-2 |
| PTC-10XV11 | No Cross |
| PTC-10WV11 | No Cross |
| PTC-10YV11 | No Cross |
| PTC-10GV13 | 3309P-3 |
| PTC-10LV13 | 3309P-2 |
| PTC-10MV13 | 3309P-3 |
| PTC-10KV13 | 3309P-2 |
| PTC-10XV13 | No Cross |
| PTC-10WV13 | No Cross |
| PTC-10YV13 | No Cross |
| PT-15/PTC15 | No Cross |

| Rohm | Kingtronics |
|---------------------------|-------------|
| SURFACE MOUNT/SINGLE-TURN | |
| MVR22 | No Cross |
| MVR34 | No Cross |
| MVR32 | C3305 |
| THROUGH-HOLE/SINGLE-TURN | |
| GV4G | No Cross |
| GV4G | No Cross |
| GV4J | No Cross |
| GV4J | No Cross |
| GV4W | No Cross |
| GV4W | No Cross |
| THROUGH-HOLE/MULTITURN | |
| GV6P | No Cross |
| GV6S | No Cross |
| GV6U | No Cross |
| GV6UT | No Cross |
| GV6V | No Cross |
| GV6VT | No Cross |
| J9P | 3296P |
| J9W | 3296W |
| J9X | 3296X |
| J9Y | 3296Y |
| J9Z | 3296Z |
| RJC07R | No Cross |
| RJC07RK2 | No Cross |
| RJC097P | 3006P |
| RJC097PK | No Cross |
| RJC097PK1 | No Cross |
| RJC097PK2 | No Cross |
| RJC097X | 3006Y |
| RJC261W | 3266W |
| RJC261X | 3266X |
| RJC26W | 3266W |
| RJC26X | 3266X |
| SURFACE MOUNT/SINGLE-TURN | |
| G31A | No Cross |
| G31B | No Cross |
| G3A | No Cross |
| G3B | No Cross |
| G41A | No Cross |
| G41B | No Cross |
| G41BF | No Cross |
| G41C | No Cross |
| G41SA | No Cross |
| G4A | No Cross |
| G4B | No Cross |
| G4BF | No Cross |
| G4C | No Cross |
| G4D | No Cross |
| G4E | No Cross |
| G4SA | No Cross |
| TRG042S1 | No Cross |
| TRG043S1 | No Cross |
| TRG043S4 | No Cross |
| VG025CHXT*** | C3305 |
| VG035CHXT*** | C3305 |
| THROUGH-HOLE/SINGLE-TURN | |
| GF063X | 3362X |
| GF063X1 | 3362W |
| G12 Series | No Cross |
| GF04 Series | No Cross |
| GF063P | 3362P |
| GF063P1 | 3362P |

| THROUGH-HOLE/SINGLE-TURN (Contd.) | |
|-----------------------------------|-----------|
| GF063P1K | No Cross |
| GF063P1T | No Cross |
| GF063P2 | 3362R |
| GF063PK | No Cross |
| GF063PT | No Cross |
| GF063S | 3362S |
| GF063S1 | 3362Z |
| GF063S1K | No Cross |
| GF063S1T | No Cross |
| GF063SK | No Cross |
| GF063ST | No Cross |
| GF063U | 3362U |
| GF063U1 | 3362U |
| GF063UK | No Cross |
| GF063UT | 3362U (R) |
| GF063UT, UT2 | 3362U |
| GF063V | 3362M |
| GF063V1 | 3386C |
| GF063V1K | No Cross |
| GF063V1T | No Cross |
| GF063VK | No Cross |
| GF063VT | 3362M (R) |
| GF063VT, VT2 | 3362M |
| GF063W | 3362H |
| GF063WK | No Cross |
| GF063X | 3362X |
| GF063X1 | 3362W |
| GF063X1K | No Cross |
| GF063XK | No Cross |
| GF063Y | 3386Y |
| GF063Y1 | 3386F |
| GF06P | 3362P |
| GF06P1 | 3362P |
| GF06P2 | 3362R |
| GF06S | 3362S |
| GF06S1 | 3362Z |
| GF06U | 3362U |
| GF06U1 | 3362U |
| GF06UT | 3362U (R) |
| GF06V | 3362M |
| GF06V1 | No Cross |
| GF06VT | 3362M (R) |
| GF06W | 3362H |
| GF06X | 3362X |
| GF06X1 | 3362W |
| GF06Y | No Cross |
| GF06Y1 | No Cross |
| RJC06F | No Cross |
| RJC06P | 3329P |
| RJC06S | 3329S |
| RJC06W | 3329H |
| RJC06X | 3329W |

| Vishay-Dale | Sfernice Spectrol | Kingtronics |
|-------------------------|-------------------|-------------|
| SURFACE MOUNT/MULTITURN | | |
| TSM4YL | No Cross | |
| TSM4YJ | No Cross | |
| TSM4ZL | No Cross | |
| TSM4ZJ | No Cross | |
| TSM43YL | No Cross | |
| TSM43YJ | No Cross | |
| TSM43ZL | No Cross | |
| TSM43ZJ | No Cross | |
| TSM53YL | No Cross | |
| TSM53YJ | No Cross | |
| TSM53ZL | No Cross | |
| TSM53ZJ | No Cross | |
| TS6X | 3269X | |
| TS6Z | 3269P | |
| TS6Y | 3269W | |
| TS63X | 3269X | |
| TS63Z | 3269P | |
| TS63Y | 3269W | |
| SM-4TW | No Cross | |
| SM-4TA | No Cross | |
| SM-4TB | No Cross | |
| SM-4ETW | No Cross | |
| SM-4ETA | No Cross | |
| SM-4ETB | No Cross | |
| SM-4W | No Cross | |
| SM-4A | No Cross | |
| SM-4B | No Cross | |
| SM-4EW | No Cross | |
| SM-4EA | No Cross | |
| SM-4EB | No Cross | |
| 5W | No Cross | |
| 5X | No Cross | |
| ST-5TW | 3269W | |
| ST-5TX | 3269X | |
| ST-5TP | 3269P | |
| ST-5TR | No Cross | |
| ST-5ETW | 3269W | |
| ST-5ETX | 3269X | |
| ST-5ETP | 3269P | |
| ST-5ETR | No Cross | |
| ST-5MW | 3269W | |
| ST-5MX | 3269X | |
| ST-5MP | 3269P | |
| ST-5MR | No Cross | |
| ST-5EMW | 3269W | |
| ST-5EMX | 3269X | |
| ST-5EMP | 3269P | |
| ST-5EMR | No Cross | |
| ST-5W | 3269W | |
| ST-5X | 3269X | |
| ST-5P | 3269P | |
| ST-5R | No Cross | |
| ST-5EW | 3269W | |
| ST-5EX | 3269X | |
| ST-5EP | 3269P | |
| ST-5ER | No Cross | |
| THROUGH-HOLE/MULTITURN | | |
| T6XA | 3266Z | |
| T6XB | 3266X | |
| T6YA | 3266Y | |
| T6YB | 3266W | |
| T6ZA | No Cross | |
| T6ZB | 3266P | |
| T63XA | 3266Z | |
| T63XB | 3266X | |
| T63YA | 3266Y | |
| T63YB | 3266W | |

| THROUGH-HOLE/MULTITURN (Contd.) | |
|---------------------------------|----------|
| T63ZA | No Cross |
| T63ZB | 3266P |
| T9XA | 3296X |
| T9XB | 3296Z |
| T9YA | 3296W |
| T9YB | 3296Y |
| T9Z | 3296P |
| T93XA | 3296X |
| T93XB | 3296Z |
| T93YA | 3296W |
| T93YB | 3296Y |
| T93Z | 3296P |
| T18 | 3006P |
| T18T | No Cross |
| T19P | 3006P |
| 1240X | 3266X |
| 1240W | 3266W |
| 1240P | 3266P |
| 1202P | No Cross |
| 1202Y | No Cross |
| 1202L | No Cross |
| 1202LB | No Cross |
| 1280G | 3006P |
| 1285G | 3006P |
| 1208P | No Cross |
| 1208Y | No Cross |